Selvam College of Technology (Autonomous), "A" Grade by NAAC, UGC recognized 2(f) Status, Approved by AICTE – New Delhi, Affiliated to Anna University Namakkal – 03. www.selvamtech.edu.in

# DEPARTMENT OF CIVIL ENGINEERING CE3502- STRUCTURAL ANALYSIS-1

## **2 MARKS QUESTIONS**

### **UNIT-1-ANALYSIS OF TRUSSES**

S.No	QUESTIONS	co's
1.	Define static indeterminacy of structures.  If the conditions of statics i.e. $\sum H = 0$ , $\sum V = 0$ and $\sum M = 0$ alone are not sufficient to find either external reactions or internal forces in a structure. The structure is called static indeterminacy of	CO1
	structures.	
	Define static determinate structures.	
2.	If the conditions of statics i.e. $\Sigma H = 0$ , $\Sigma V = 0$ and $\Sigma M = 0$ alone are sufficient to find either external	CO1
	reactions or internal forces in a structure. The structure is called static determinacy of structures.	
3.	Differentiate perfect and imperfect frame.	
	A structural frame that is stable under loads imposed upon it from any direction is known as perfect	CO1
	frame.	
	A structural frame is unstable if one of its members were removed or one of its fixed ends became	
	hinged is known as imperfect frame.	
4.	Explain Mohr's correction.	
	The Williot diagram does not give the true deflection of the joints but the same can be modified and	CO1
	correlated to the true deflection by applying certain correction is known as Mohr's correction.	
	State the basic unit load formula.	
	i) Find the forces P1, P2, in all the members due to external loads.	
5.	ii) Remove the external loads and apply the unit vertical point load at the joint if the	CO1
	vertical deflection is required and find the stress.	
	iii) Apply the equation for vertical and horizontal deflection.	
6.	What is the significance of unit load method?	
	The external load is removed and the unit load is applied at the point, where the deflection or rotation	CO1
	is to found.	
	Write down the Castigliano's first theorem.	
7	The partial derivative of the total strain energy with respect to an applied force or moment gives the	CO1
7.	displacement or rotation at the point of application of the force and in the direction of application of	CO1
	the force.	
8.	State and explain the principle of virtual work.	CO1

Selvam College of Technology (Autonomous), "A" Grade by NAAC, UGC recognized 2(f) Status, Approved by AICTE – New Delhi, Affiliated to Anna University Namakkal – 03. www.selvamtech.edu.in

	The principle of virtual work is based on the conservation of energy for a structure which implies	
	that work done on a structure by external loads is equal to workdone on a structure by internal	
	loads.	
	Define internally and externally indeterminate structures.	
9.	Internally indeterminate structures: In a pin jointed frames redundancy caused by too many	
	members is called internally indeterminate structures or internal redundancy. Externally	CO1
	indeterminate structures: In a pin jointed frames redundancy caused by too many supports is called	
	externally indeterminate structures or external redundancy.	
	Define degree of freedom.	
10.	In a structure the number of independent joint displacement that the structures can undergo are known	CO1
	as degree of freedom. It is also known as kinematic indeterminacy.	